

Bottom panel

Figure 1

SPECTRUM


0120375R1 Page 1 of 2

Figure 2

povettylene side

3. Install Cube

- 1. Using the quick-release, remove the door to provide better access.
- 2. Install the (4) bumper stops to the base panel as shown with one 7mm x 30mm JCW screw each. Figure 3.
- 3. Place the cube assembly into the lectern.
- 4. Secure the cube to the base panel with (1) #14 x 7/8" PHSM screw and tighten securely.
- 5. The bumper stops can be rotated if adjustment is necessary.



The rack cube provides 16RU of rack space and is easily removed from the lectern. This simplifies installation of equipment and provides the ability to integrate equipment remotely. The cube can be installed into the lectern at a later date or when convenient.

The cube also provides mounting capabilities for multiple cooling fans if necessary. Compatible with most 4.75" cooling fans with 4.13" mounting hole spacing (12 mounting locations available).

925 FIRST AVENUE, CHIPPEWA FALLS, WI 54729 / 800-235-1262 / 715-723-6750 / WWW.SPECTRUMFURNITURE.COM