

# Assembly Instructions

## ⚠ Important ⚠


Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.

Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

[www.spectrumfurniture.com](http://www.spectrumfurniture.com)  
800-235-1262, 715-723-6750

*Thank you for purchasing Spectrum products!*

*(One of the following logo panels will be included)*




(1) 0177144  
67.375 x 13" Audience-side logo  
for 72"W desk

(1) 0177145  
55.375 x 13" Audience-side logo  
for 60"W desk

(1) 0177146  
39.375 x 13" Audience-side logo  
for 44"W desk


(1) 0177147  
31.375 x 13" Audience-side logo  
for 36"W desk




## Printed Logo Panels for Esports GG Gaming Desk

Audience-side logo  
37422 - 72"W Desk  
37423 - 60"W Desk  
37424 - 44"W Desk  
37425 - 36"W Desk

End panel logo  
37426 - End panel logo



(1) 0177148  
End panel logo  
27.5" x 18.75"



(4) 0110254  
2" x 3" Hook fastener

(4) 0110255  
2" x 3" Loop fastener

## Audience-side logo installation

1. Attach hook and loop to the top edge of the panel.
2. Place lower edge of panel into into channel.
3. Apply panel to desk modesty panel.

## End logo installation

1. Attach hook and loop to the corners of the panel.
2. Apply panel to desk end panel.

