

Assembly Instructions

⚠ Important ⚠


Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.

Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

www.spectrumfurniture.com
800-235-1262, 715-723-6750

Thank you for purchasing Spectrum products!

(One of the following logo panels will be included)




(1) 0177144
67.375 x 13" Audience-side logo
for 72"W desk

(1) 0177145
55.375 x 13" Audience-side logo
for 60"W desk

(1) 0177146
39.375 x 13" Audience-side logo
for 44"W desk


(1) 0177147
31.375 x 13" Audience-side logo
for 36"W desk




Printed Logo Panels for Esports GG Gaming Desk

Audience-side logo
37422 - 72"W Desk
37423 - 60"W Desk
37424 - 44"W Desk
37425 - 36"W Desk

End panel logo
37426 - End panel logo



(1) 0177148
End panel logo
27.5" x 18.75"




(4) 0110254
2" x 3" Hook fastener

(4) 0110255
2" x 3" Loop fastener

Audience-side logo installation

1. Attach hook and loop to the top edge of the panel.
2. Place lower edge of panel into into channel.
3. Apply panel to desk modesty panel.



End logo installation

1. Attach hook and loop to the corners of the panel.
2. Apply panel to desk end panel.