# Assembly Instructions

### 🛕 Important 🛕

Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.

Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

> www.spectrumfurniture.com 800-235-1262, 715-723-6750

Thank you for purchasing Spectrum products!



(4) 052605 1/4-20 x 15mm JC bolt



(1) 025039 Hex wrench



(2) 025068 1/4-20 x 15mm Glide



(1) 025069 Glide wrench

Mid-Support Leg for IMC 68104 - 29"H 68154 - 36"H



4mm Hex wrench (included)



Glide wrench (included)

## 1. Install glides

1. Install the (2) glides onto the mid-support leg. Figure 1. (The glides can be rotated to level the unit later.)

### Install Mid-Support Leg

- 1. Align the mid-support leg and wall filler panel mounting holes as shown . Figure 1.
- 2. Attach the mid-support leg to the wall filler panels with (4) 1/4-20 x 15mm JC bolts. (Note: These bolts come with the wall filler panels).
- 3. Set both worksurfaces onto the console with the seam centered over the mid-support leg.
- 4. Attach to worksurfaces with (4) 1/4-20 x 15mm JC bolts.

Note: Mid-support legs are used to connect and support the seam of two worksurfaces.

