Assembly Instructions

Important A

Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.

Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

www.spectrumfurniture.com

800-235-1262, 715-723-6750

Thank you for purchasing Spectrum products!



(1) Flip-up shelf assembly



(1) 039622 2" Grommet

For metal side panels

For laminate side panels



(16) 0100167 8-32 x 1/2" PH Thread-cutting screw



(16) 051696 8-32 x 1" PHMS



(16)02853/16 Flat Steel Washer




(16) 021588 8-32 Keps Nut

1. Before You Begin


Determine:

- · The side of the lectern the shelf will be installed. (Left or right)
- The shelf position: (Upper or lower)
- Type of side panels your lectern has (metal or laminate) Figure 1A










Flip-up Shelf for Compact Lectern 55537



Installation video available See www.spectrumfurniture.com





Upper shelf position holes

Lower shelf position holes

Figure 1B

Attaching to laminate side panels:

- 1. Open the lectern door and remove the rack cube (if equipped).
- 2. From inside the lectern, use a drill with a 3/16" drill bit and slowly drill out the corresponding pre-drilled pilot holes located on the laminate side panel. Figure 1B. Masking tape can be used on the exterior to minimize chip-out.



Drill with 3/16" drill bit





