Assembly Instructions

▲ Important ▲

Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.

Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

> www.spectrumfurniture.com 800-235-1262, 715-723-6750

Thank you for purchasing Spectrum products!



(1) 0167429 Worksurface



Companion Equipment Rack 55559








Assembly tip: Do not tighten component fasteners completely until all have been installed. Keeping them loose will help with alignment between parts during assembly.



Side panel



(2) 0100437 24.5" Rack Rail



(2) 0167671 Frame



(one acrylic, one laminate panel)



(4) 0190604 3" Twin wheel locking stem caster 1/2-13 x 1"



(2) 0169174 Catch



Parts Bag

(1) 0119468 Recessed bumper



(48) 0190174 #8 x 3/8" PHSM



(8) 0106543 1/4-20 Keps nut



(4) 0101382 #14 x 7/8" PHSM

1 Attach frames to worksurface




Figure 1

2 Attach base panel to frames

1. Align the base panel between the frames and secure with (4) #8 x 3/8" PHSM screws. **Figure 2**.





Figure 2

3 Attach side panels



4 Attach legs

- 1. Insert leg tabs into side panel slots. Figure 4.
- 2. Secure each leg with the (4) threaded studs and (4) 1/4-20 Keps nuts and tighten securely.




5 Install casters

1. Install (4) casters and tighten securely with wrench. Figure 5.

6 Flip rack box upright

1. Flip the rack box upright. Figure 6.





Attach rack rails


- Align the rack rails as shown (short legs facing inward) and attach each to a frame with (3) #8 x 3/8" PHSM screws. Figure 7.
 Tighten securely.



Figure 7

8 Attach door catches

- 1. Attach catch to the right side of the unit with (2) #8 x 3/8" PHSM screws. Figure 8.
- 2. Repeat on opposite side of rack box.



9 Attach door assemblies

- 1. Open hinge of the door assembly 180°. Figure 9.
- 2. Align the hinge mounting holes with the frame and secure with (4) #8 x 3/8" PHSM screws.
- 3. Repeat on opposite door.

Note: The acrylic door assembly installs on the instructor-side, and the laminate panel door assembly on the audience-side.

Acrylic door assembly on instructor side




Figure 9