Assembly Instructions


Important

Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.

Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

www.spectrumfurniture.com 800-235-1262.715-723-6750

Thank you for purchasing Spectrum products!



1. Connect two charging pillars together

1. Set one charging pillar on top the other in the final location. Figure 1.1.

a

n n a n

n

n n

n n n n n n n


a

Wall

Nortsurface


Or ROOF


- Connect the two units together by installing the (4) flat brackets with 8-32 screws. Figure 1.2.
- 3. Tighten securely.



Stacking Kit for Collectiv8[™] Charging Pillar 55395

- 55395 Stacking Kit connects two Collectiv8 Charging Pillars
- together and secures them to a worksurface or floor
- Max recommended stack height: 2 units
- Fasteners included for concrete floor applications





SPECTRUM

2. Secure assembled pillars to worksurface or floor


Install the (4) L-brackets to the unit as shown with 8-32 x 1/2" PH

Thread cutting screws. Figure 2.1, 2.2. (Use slotted hole on bracket).

1.

2.

Tighten securely.



3. Mark hole locations onto worksurface or floor. 4. Pre-drill the marked locations with a 3/16" drill bit. 5. Install wood or concrete screws. Figure 2.2. n (î a 0 a Note: For concrete applications, a 3/16" hole is recommended for a each 1/4" Tapcon hex screw. Ç1 0 (1) 8-32 x 1/2" PH Thread cutting screw (1) #14 x 1-3/4" PHSM in slotted hole screw (wood) (î or a (1) 1/4" x 2-1/4" Tapcon Hex screw (concrete) 0 0 0 0 0 (1) 8-32 x 1/2" PH 0 Thread cutting screw L-bracket L-bracket (1) 8-32 x 1/2" PH Thread cutting screw L-bracket Figure 2.1 Figure 2.2