

Assembly Instructions

⚠ Important ⚠

Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.


Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

www.spectrumfurniture.com
800-235-1262, 715-723-6750


Thank you for purchasing Spectrum products!




(2) 039622
2" Round Grommet



(2) 0102063
1/4-20 x 35mm
JC bolt



(1) 025039
4mm Hex
Wrench



Blank Overbridge Panel

96501 - Small
96504 - Medium

96507 - Large
96510 - XL

1. Layout cutout(s) on overbridge panel

- Before you begin, refer to the panel dimensions in **Figure 1** and the chart below for maximum recommended cutout sizes.
- Identify the size and position (left, centered, or right) of each cutout needed.

	A (Max cutout width)	B (Overall panel width)
96501 - Small	13.25 [33.7 cm]	21.25 [54 cm]
96504 - Medium	19.25 [48.9 cm]	27.25 [69.2 cm]
96507 - Large	25.25 [64.1 cm]	33.25 [84.5 cm]
96510 - XL	33.25 [84.5 cm]	41.25 [104.8 cm]





Figure 1

Note: The max cutout areas shown are general recommendations only. The final location of the cutout(s) on the panel will be determined by:

- The size of the cutout(s)
- The vertical depth of the installed device
- Location preference of each device (left, centered, right)
- The available worksurface opening under the overbridge on your specific Spectrum lectern.

- Identify the depth of your device to verify it will not interfere with the worksurface or any other objects under the overbridge when the panel is attached. **Figure 2.**
- When the cutout location(s) have been determined, locate and mark the exact cutout area(s) on the panel with a pencil. **Note: Using masking tape on cut lines will minimize laminate chipping while cutting.**




Figure 2

2. Make panel cutouts

- Carefully make the cutout(s) in the panel using a jigsaw or router.

3. Attach panel to overbridge frame

- Set the panel into the overbridge frame opening. Note: It may be necessary in some cases to install the electronic device into the panel **before** attaching the panel to the overbridge.
- Secure with (2) 1/4-20 x 35mm JC bolts and tighten securely.
- Install (2) 2" grommets.

Note: The overbridge panel is symmetrical. Rotating or flipping the panel 180° and re-attaching to the overbridge will allow you to place the cutout on the opposite side of the overbridge if necessary.




Figure 3